



# SENROLL

## Enrollment Reader

### Overview

The SENROLL Enrollment Reader can be used in conjunction with the Schlage Security Management System (SMS) Select, Premier or Enterprise Software to facilitate automatic enrollment of online and/or offline credentials into your access control system. Automatic enrollment eliminates the time involved in manually entering credential data and greatly reduces the potential for human error. The SENROLL contains read heads for:

- Proximity / Smartcard
- iButton®
- Magnetic Stripe

The SMS software will automatically store the credential data in the database upon presentation of a credential to one of the read heads. This all-in-one unit allows the end-user to utilize different credential technologies or migrate to different technologies in the future. The SENROLL can be connected to the SMS workstation using either a serial port or a USB port (the latter via an inline USB/Serial converter that is included with the reader). For your convenience, the unit can be located at the SMS workstation for easy enrollment. No additional hardware is required.



<b>Specifications</b>	
<b>Dimensions</b>	1.53" H x 4.20" W x 6.92" D
<b>Power supply</b>	included
<b>Power consumption</b>	100mA
<b>Ambient Temperature</b>	0° to 70° C or -40° to 185° F
<b>Humidity</b>	10% to 90% (non-condensing)
<b>Maximum distance to SMS PC</b>	50 feet, RS-232 communication
<b>Recommended cable</b>	included
<b>Please refer to SMS Manual for supported formats</b>	

#### **ORDERING INFORMATION**

**SENROLL**- Provides multiple read head technologies for entering credential data into the Schlage Security Management System database (SMS Select, Premier or Enterprise)

*NOTE: Please specify if using with multi-technology cards*

